

VINYL INSTALLATION GUIDE

1 SURFACE PREPARATION

- Surface temperature should be at least +10° Celsius and free from wax or grease.
- Decals should not be placed on freshly painted surfaces.
- Tools needed: Squeegee, tape measure or ruler, painters tape, lint free cloth or paper towel and cleaner (eg. windex)



Make sure the surface is clean, any dirt, dust or grease will inhibit the surface adhesion.



Mark and measure where you want the decal placement.



Using a low tack tape such as painters tape secure the decal to the surface at it's center



Carefully peel back the decal from the backing paper to the center point, cut the backing paper



Using firm pressure, squeegee the decal from the center out toward the edges.



With half of the decal adhered to the surface, you can now remove the low tack tape.



Carefully peel back the second half of the backing paper.



Squeegee down the second half of the decal using the same method in the outlined above.



The decal should now be securely adhered to the surface.

NOTE:

- Depending on surface, temperature and application execution, most decals can be exposed to normal environmental conditions immediately. Once the decal is squeegeed the decal cannot be removed and reapplied with any significant chance of success. Fully cured and set adhesion may vary depending on temperature and surface conditions.